

Balatonboglár állomás

				4.	1488+51
A	1482+00	B	1503+06	6.	1488+51
K1	1489+95	V1	1494+88	8.	1488+78
K2	1489+95	V2	1494+88	10.	1490+21
K3	1489+13	V3	1495+73	1.	1496+92
SR2	1483+64	SR1	1501+43	3.	1496+36
SR4	1487+95	KS4	1489+23	5.	1496+41
KS2	1489+28	2.	1488+16	7.	1492+69
				KS1	1495+82

