



Balatonfenyves állomás

1637+72



Fonyód

Balatonmáriafürdő



1628+27

1637+15

1644+68

1608	1609+10	1661	1660+05	6.	1633+02
A	1625+82	B	1646+90	1.	1641+35
K1	1633+67	V1	1640+14	3.	1641+01
K2	1633+79	V2	1639+99	5.	1640+66
K3	1633+79	V3	1639+99	7.	1640+60
K4	1633+00	V4	1640+01	1/1.	1642+58
KS1	1641+85	SR1	1641+15	1/2.	1644+58
VS1	1643+15	2.	1632+34	1/3.	1646+40
SR 2	1626+32	4.	1632+68	1/4.	1646+74